




2. Remove quick-release pin that holds flag pole to slider. **Hint:** Re-insert pin at bottom of flag pole for E-Z storage.



3. Depress snap button on flag pole and telescope inner flag pole into outer flag pole.



4. Remove flag banner from pole for storage or simply pull flex rod to disengage. Lay flex rod parallel to flag pole and roll flag banner around pole. Wrap Velcro® strap around flag and flag pole and cinch for storage.

Note: If desired, you may take sliders off of Instant Shelter® legs. If you choose to take sliders off follow slider installation procedures and slide the slider off of outer leg.

For online warranty, service, parts and accessories as E-Z as 1-2-click, contact us at

www.ezup.com

Ask about our other E-Z UP® Instant Products™

IMPORTANT INFORMATION

IMPORTANT! Read this information before proceeding. It is the user's responsibility to take the following precautions at all times.

- Use caution when handling the E-Z UP® folding frame. Avoid pinching hands or fingers as frame opens or closes.
- Always stake or weight down your E-Z UP®. Do not use in any potentially windy or rainy weather. Wind and rain can damage the E-Z UP® Instant Shelter® and may also result in injury to you or others. Therefore, do not rely on shelter for protection in heavy or prolonged rain storms.
- Do not use shelter or flag banner in a lightning storm.
- The E-Z UP® Instant Shelter® is designed as a temporary shelter. Do not leave up for extended periods.
- Do not leave your E-Z UP® Instant Shelter® unattended.
- Keep all flame and heat sources away from fabric top. Do not build fires within shelter or near shelter.

Fire retardant - meets CPAI-84 requirements.

We Make Life E-Z!™ INTERNATIONAL E-Z UP, INC.

Corporate and Manufacturing Headquarters
1601 Iowa Avenue, Riverside, California 92507
(909) 426-0060 • Fax (909) 426-0063

www.ezup.com
Customer Service Hot Line

800-SHADE ME
7 4 2 3 3 6 3

Covered under one or more of the following patents: 4,607,656; 4,924,896; 5,244,001; 5,421,356; 5,485,863; 5,490,533; 5,511,572; 5,632,292; 5,632,293; 5,794,546; 5,797,412; 5,813,425; 5,865,127; 5,921,260; 5,934,301; 6,041,800; 6,070,604; 6,076,312; 6,129,102; 6,138,702; 6,192,910; 6,230,729; 6,240,940; 95704390; 94/2354; 91461; 132167; 95/0693; 95/6140; 95/6141; 84107895; 684,978; 2123096; 190486; 289754; 215344; 701077; 2128935; 2949648; 48648; DE 695 10 919 T2; WO96/03561. International Design Registration No. DM/009515 Benelux Design Registration No. 16959-04. Other US and foreign patents pending. © Copyright 2001 International E-Z UP, Inc. USA. All rights reserved.

12070701

E-Z UP® INSTANT SHELTER®



HOW TO INSTALL YOUR E-Z UP® FLAG BANNER™

Take time to learn how to provide years of durable and safe use from your E-Z UP® Flag Banner™. After reading these instructions carefully, if you have any need of assistance, call our Customer Service Department.



Customer Service Hot Line
(800) SHADE ME
7 4 2 3 3 6 3
www.ezup.com

OWNER'S MANUAL

WHAT'S INCLUDED

- Fabric flag banner
- Quick-release pin
- Flag pole with attached black fiberglass flex rod
- 2-prong slider
- Velcro® strap

Important: Read instructions from start to finish before attempting to install Flag Banner™.

- 1.** Completely set up the E-Z UP® Instant Shelter® by referring to the owner's manual provided with the shelter.



- 2.** Securely insert black flex rod into hole on flag pole. Flex rod will be at a 23° degree angle.

HOW TO SET UP FLAG BANNER




- 3.** Slide flag banner fabric onto flex rod by inserting rod into sleeve along 23° degree angle.




- 4.** Secure flag banner by wrapping three Velcro® straps on flag fabric around flag pole, match Velcro® straps located on back of flag and press firmly together.

HOW TO SET UP FLAG POLE



- 5.** Lift flag pole slightly off of ground and pull out inner flag pole until snap button locks.



- 6.** With a partner, raise the legs of the E-Z UP® frame to the tallest height adjustment. Depress the snap button and pull inner leg free from the outer leg by lifting upward while pulling inner leg out. (Be careful not to pullout plastic inserts in legs.)



- 7.** Slide the two-prong slider onto the outer leg with slider tab pointing outside of shelter where the Flag Banner will be attached. If desired you may leave banner sliders on shelter once the unit has been taken down. **Important: If the shelter also has rail skirts, a three-prong slider will be required to accommodate both rail skirts and flag banner. Sliders may be purchased by calling customer service or on our website.**



- 8.** With one hand holding the outer leg below the slider, insert the inner leg back into the outer leg until snap button engages. The snap button will hold and support the slider in place.



- 9.** Attach the flag pole to the E-Z UP® frame by positioning the two holes at the bottom of the flag pole with the hole in the slider tab.



- 10.** Attach the quick-release pin to the slider by gently pulling the clasp and pin simultaneously in opposite directions and threading the pin through the slider and then the two holes in the flag pole. Close the quick-release pin by pulling the clasp over the end of the pin. Note: the pins will become more flexible with repeated use.



- 11.** Secure the flag pole to the frame just under the E-Z UP® valance. Wrap the provided Velcro® strap around the flag pole and E-Z UP® leg. Insert Velcro® strap into the buckle and cinch until taught. Wrap Velcro® strap back around buckle, match Velcro® strips and press firmly together.

HOW TO TAKE DOWN FLAG BANNER AND POLE



- 1.** Release Velcro® strap that attaches flag pole to frame.