

Instructions

Please read each step before you attempt to set up. Save these instructions for future reference. Return the Warranty Card within 10 days of purchase.


How To Set Up

*Note: First Time Attachment Is Required.


Top and frame are shipped unattached to avoid damage. A first time set up requires that top be bolted on to the frame. This first time set up takes longer than future set ups. Once top is permanently attached to frame, set up and take down are easily accomplished within seconds.




1. Place your E-Z UP® Instant Shelter® frame in the center of area to be sheltered. With partner on opposite side, grasp two outer legs, slightly lift off ground and step backwards, stopping at full arms' length - approximately 3/4 it's total size.




***2.** Gently unfold the fabric top and place it over the open shelter. Align the four corners of the top over the four corners of the frame.




***3.** Attach the top to the frame by matching the Velcro® strips on the top with the Velcro® strips of the frame. Push the Velcro® firmly together at each corner.




***4.** To secure the top to frame, align grommet holes on valance with four bolts in frame




***5.** With wrenches provided, remove the nut from each bolt (one at a time) and pull bolt out completely while holding trusses, washers spacer and angle bracket in place. Line up fabric top grommet hole with the trusses and slide bolt through all parts.



***6.** Put nut back on bolt located on the inside of the trusses. Tighten nut until snug and grommet can still rotate without a great deal of free play.



7. Grasp the bottom of the diamond shaped area of trusses, on opposite sides. Lift up and step backwards until shelter is fully opened. **BE CAREFUL NOT TO PINCH FINGERS.**



8. Engage the auto slider at each corner by pushing up with one hand while holding down the top of the leg with the other hand. The snap button will engage the hole. Then pull down the hem of the top. Repeat at all four corners.




9. Lift two adjacent outer legs and slide out the inner legs until the snap button locks. Repeat on the opposite legs. **BE SURE TO ADJUST TWO LEGS AT ONE TIME TO AVOID FRAME DAMAGE.**

***Note: ONCE TOP IS PERMANENTLY ATTACHED, ONLY PERFORM STEPS 1 AND 7 - 9 TO SET UP.**

How To Take Down



1. With partner, depress snap button on legs and telescope inner legs into outer legs. Repeat on the opposite legs - making sure to do two legs at a time.



2. Release the auto slider at each corner by first lifting hem of top. With one hand, push up on truss near slider, depress snap button. **Note:** It is easier to depress the snap button when the shelter weight has been removed from the button.



3. Grasp the top diamond on opposite sides by "close" sticker. Lift the shelter up slightly and shake it while stepping towards your partner until the unit is 3/4 closed. With each partner grasping two outer legs, push frame together to fully close it - Be careful not to pinch fingers. Store frame in cover bag.